


USB Voice Recorder User's Manual

● Appearance and Buttons

1. Turn on/off button
2. Status light
3. Reset hole



● Instructions:

◆ One button recording

Push the power button to “ON” position, the status light becomes red, then to blue, the recorder starts recording.

◆ Stop recording

When recording, switch the button to “OFF” position or connect it to the computer, the blue light will turn off, then it stops and save the recording.

◆ Playback

Connect the USB Voice Recorder to a computer. Since the USB Voice Recorder does not require a driver, the computer will recognize it. A pop up window should appear and now you can play the recordings on your computer.

◆ Charging

Plug the USB Voice Recorder into a computer's USB port. The status light will begin to blink meaning that it is now charging. When fully charged, the status light remains red. After a full charge the USB Voice Recorder can operate for around 15 hours.

(NOTE: If the battery is low during a use, the red status light will blink. Please stop recording and charge until the red status light remains lit.)

◆ Reset

If the Recorder experiences any difficulties or does not function normally it may need to be reset. Please insert a pointed object such as a toothpick or an edge of a paperclip into the hole until the reset button is pressed. Now the unit has been reset. Please note that any recordings that are on the recorder will be erased when the reset button is pressed.

● Technical Specifications:

Specifications	
Size: 70mm×21mm×9.4mm	Weight: 0.46 ounces
Internal Battery: 3.7V 110mAh (lasting about 15 hours when full charged)	
Recording format: WAV	
Recording bit rate: 128K bps	
Recording Time: 4GB: about 70hours	
Support system: Windows2000/XP/vista/7/8.1 or newer	

